Loose Ends

After adjusting the straps, loose ends can be taped in position or fed back through the buckle.

Start

Mid-way





Finished





Harness back

Warranty

Any claim under this warranty must be made within 30 days of the date of purchase of the product. To make a claim under the warranty, take the product (with proof of purchase) to the store where you purchased the product or contact Tech Vest Australia Pty Ltd at the address below.

Tech Vest Australia Pty Ltd will pay your reasonable, direct expenses of claiming under this warranty. You may submit details and proof of your expense claim to Tech Vest Australia Pty Ltd for consideration.

This warranty is given by Tech Vest Australia Pty Ltd ABN 49 118 216 229 ,Unit 6, 30 Shipley Drive Rutherford NSW 2320.

This warranty is provided in addition to other rights and remedies you have under law: Our goods come with guarantees which cannot be excluded under the Australian Consumer Law. You are entitled to replacement or refund for a major failure and to compensation for other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



Harnessing the Future

Unit 6/30 Shipley Drive Rutherford NSW 2320 Phone: 02 4932 1876 E-mail: info@techvest.com.au

Visit us at www.techvest.com.au



TECHVEST

Harnessing the Future



User information

Tech Vest® load carrying harness



Constructed from a heavy duty knitted mesh and abrasive resistant Cordura® nylon, the Tech Vest® is fully adjustable to provide a comfortable fit for the modern underground worker.

The materials used in the Tech Vest ® provides a comfortable load carrying harness which "breathes" through the use of the knitted mesh. Moisture absorption of the padding is reduced by utilizing quality, moisture resistant, high density foam.

Underground visibility is increased through the incorporation of 3M Scotchlite TM reflective panels on the Tech Vest $^{\mathbb{R}}$.

Adjusting the Tech Vest®

Initial waist adjustments can be made by using the main straps at the rear of the vest.

Further quick adjustments can be easily made by using the two main waist straps at the front of the vest.

The quick adjustment straps at the front of the Tech Vest® allow for additional clothing that may be required to be worn.

Each shoulder pad can be adjusted to allow the Tech Vest® to sit evenly around the waist.





Small tools are kept in place with specially designed pouches on the battery and self rescuer pouches

Remember to buckle up all pouches



Safety glasses, tools or instruments will fit into the front pouches.



